Specification

Main fuse block

Fuse	Protected circuit
BTN 60A	Light switch, Heater and air conditioner Circuit also protected in fuse box (STOP 20A, HAZARD 10A, ROOM 7.5A, ANTENNA 10A, ILLUMI 15A, ABS 15A, SEAT BELT 30A, FOG 15A)
HEAD 30A	Headlight
RETRACTOR 30A	Retractable headlight
EGI 30A	EGI and emission control system
MAIN 100A	Starter and charge system
ABS 60A	Anti-lock brake system

97UOTX-012

Fuse box

Fuse	Protected circuit
HEATER 30A	Heater and air conditioner
DEFOG 30A	Rear window defroster
STOP 20A	Stoplight, Cruise control system
HAZARD 10A	Turn and hazard lights
ROOM 7.5A	Cargo light, Courtesy lights, Room and stop light, Warning and buzzer or chime, Door lock cylinder and ignition key cylinder light, EGI and emission control system, Warning and auto clock system, Theft-deterrent system, EC-AT control system
ANTENNA 10A	Power door lock system, Power antenna
ILLUMI 15A	Headlight
ABS 15A	Anti-lock brake system
SEAT BELT 30A	Passive shoulder belt
FOG 15A	Front fog light
CIGAR 10A	Warning and auto clock, Remoto control mirror, Heater and air conditioner
AUDIO 20A	Audio system
REAR WIPER 10A	Rear wiper and washer
SUNROOF 15A	Sunroof, Anti-lock brake system, AAS system
SOFT TOP 30A	Convertible top system
COOLING FAN 15A	Cooling fan system
WIPER 15A	Front wiper and washer, DRL system, Heater and air conditioner
ENGINE 15A	EC-AT control system. Fuel system, EGI and emission control system
METER 10A	Back-up light, Cruise control system, Shift lock system, EC-AT control system, Meter, Warning and auto clock, Cooling fan system
ANTENNA IG 10A	Rear window defroster, Starter and charge system, EC-AT control system, Power antenna, Horn, Stoplight, Power steering
POWER WIND 30A	Power window. AAS system
TURN 15A	Turn and hazard, Rear window defroster, Passive shoulder belt

97UOTX-013